



Installation Instructions Trektop Pro

Vehicle Application:
Jeep® Wrangler JK (2 Door) 2007-2017
Part Number 54862

Installation Tips

Before you begin installing your new Trektop Pro, please read all the instructions thoroughly, and watch the Bestop Installation video. (See Support section on this page)

For a Smooth fit and easier installation, the top should be installed at a temperature above 72°F. Below this temperature, the fabric may contract an inch or more, making it difficult to fit to the vehicle.

It is normal for the fabric to contract and wrinkle when stored in the shipping carton. Within a few days after installation, the fabric will relax and the wrinkles will disappear.



WARNING

Do not rely in any way on the components of this product to protect against injury or death in the event of an accident. Never operate the vehicle in excess of manufacturer's specifications.

Read and follow, precisely, all installation instructions provided when installing this product.

Failure to do so may result in a poor fit and could place occupants of the vehicle in a potentially dangerous situation.



CAUTION

Safety glasses should be worn at all times when installing this product.

WEAR SEAT BELTS AT ALL TIMES



Tools



#2 Phillips
Screwdriver



10mm, 13mm &
3/8" Wrenches



Ratchet



13mm Socket



T40 Torx
Driver




Flat Blade
Screwdriver



Safety
Glasses



3mm &
4mm Allen
Wrenches



Utility Knife



4 hours

Skill Level



3 - Moderately Difficult

Support

We're here to help!
Go to www.Bestop.com and
click on "Need Help?"



Installation Instructions Trektop Pro

Vehicle Application:
Jeep® Wrangler JK (2 Door) 2007-2017
Part Number 54862

Sugerencias de Instalación

Antes de empezar a instalar esta unidad, lea atentamente todas las instrucciones.

Para un buen ajuste:

Para facilitar la instalación, el producto debe instalarse a temperaturas superiores a 72 °F (22 °C).

Por debajo de esta temperatura, la tela puede encogerse una pulgada o más, lo que dificultaría su ajuste al vehículo.

Es normal que la tela se contraiga o arrugue cuando está guardada en la caja de empaque. A los pocos días después de la instalación, la tela se relajará y las arrugas desaparecerán.



ADVERTENCIA

Este producto se diseñó principalmente para mejorar la apariencia del vehículo y proteger a los ocupantes de las condiciones climáticas comunes. De ninguna manera piense que los componentes de este producto pueden servir como medio de contención para los ocupantes del vehículo o que pueden protegerlos contra lesiones o la muerte en caso de accidente. Este producto no protegerá a los ocupantes contra caídas de objetos. Nunca conduzca este vehículo fuera de las especificaciones del fabricante.

USE LOS CINTURONES DE SEGURIDAD EN TODO MOMENTO

Lea y siga con precisión todas las instrucciones de instalación que se proporcionan para instalar este producto. Si no lo hace, podría producirse un mal ajuste que colocaría a los ocupantes del vehículo en una situación potencialmente peligrosa.



PRECAUCIÓN

Debe usar gafas protectoras en todo momento durante la instalación de este producto.

Conseils pour l'installation

Lire toutes les instructions au complet avant de commencer l'installation de cet assemblage.

Pour un ajustement sans problème :

Afin de faciliter l'installation, ce produit doit être installé à des températures au-dessus de 72 °F (22 °C).

Sous cette température, le tissu peut rétrécir d'un pouce (2,5 cm) ou plus, ce qui rendra l'ajustement sur le véhicule difficile.

Il est normal que le tissu rétrécisse et plisse pendant qu'il est dans la boîte d'expédition. En quelques jours après l'installation, le tissu se détendra et les plis disparaîtront.



AVERTISSEMENT

Ce produit est conçu principalement pour améliorer l'apparence du véhicule et pour protéger les occupants des conditions météorologiques usuelles. Ne jamais se fier aux composants de ce produit pour se protéger de blessures ou de la mort en cas d'accident. Ce produit ne protégera pas les occupants des chutes d'objets. Ne jamais utiliser le véhicule au-delà des caractéristiques techniques indiquées par le fabricant.

PORTER UNE CEINTURE DE SÉCURITÉ EN TOUT TEMPS

Lire et suivre, très fidèlement, toutes les instructions d'installation fournies lors de l'installation de ce produit. Ne pas suivre cette consigne peut causer une installation inadéquate et mettre les occupants du véhicule dans une situation potentiellement dangereuse.



MISE EN GARDE


Des lunettes de sécurité doivent être portées en tout temps lors de l'installation de ce produit.



Installation Instructions Trektop Pro

Vehicle Application:
Jeep® Wrangler JK (2 Door) 2007-2017
Part Number 54862

Parts List







Installation Instructions Trektop Pro

Vehicle Application:
Jeep® Wrangler JK (2 Door) 2007-2017
Part Number 54862

Parts List



Rear Door Surround - Right
Part #547.04 - Right (shown)
Part #547.05 - Left
Qty. 1 of each



Window Carrier - Right
Part #509.88 - Right (shown)
Part #509.89 - Left
Qty. 1 of each



Halo - Left
Part #509.77
Qty. 1



Halo - Right
Part #509.76
Qty. 1



Halo Frame
Part #509.82
Qty. 1



Halo Center
Part #509.80
Qty. 1



Rear Arch Bow
Part #509.60
Qty. 1



Strut
Part #510.16
Qty. 2



Halo Seal (Long)
Part #510.17
Qty. 1





Rear Seal (Short)
Part #511.87
Qty. 1

Deck, Header Assembly & Fabric Top

Left Side Window


Rear Window

Right Side Window




#2 Bow Assembly
Part #541.18
Qty. 1


Step 1



Parts



Step 2




Open the passenger side Door.
Insert the pin in the bottom of the Right Door Rail into the hole in the belt rail behind the door opening.
Press the channel along the top of the Door Rail around the horizontal sport bar.


Repeat on the left side of the vehicle.

Insert one (1) M8 x 80mm Screw into each position on the Right Door Rail and tighten to 55in/lbs (4.5ft/lbs).

Repeat on the left side of the vehicle, with the Left Door Rail.



Step 1



Parts



#2 Bow Pivot Bracket
#541.88 - Right (shown)
#541.87 - Left
Qty. 1 per side

Tools




13mm Socket



Ratchet

Step 2



Cut a slit in the sport bar cover



Utility Knife

Unzip the sport bar cover over the middle cross bar, to expose the sport bar corner plate, and two hex-head bolts.

Remove these two bolts on each side of the sport bar.


Attach the Right #2 Bow Pivot Bracket to the right side sport bar plate using the two bolts you removed.

Repeat on the both sides of the Jeep.


Zip the sport bar cover closed.

Locate the vertical tab on the #2 Bow Pivot Bracket, and cut a slit in the cover to allow this tab to protrude through the cover.


Repeat on the both sides of the Jeep.



Step 1



Parts



Sunrider
Pivot Bracket
#545.74
Qty. 2



#10-32
Nylon Lock Nut
Part #316.94
Qty. 2 per side



#10-32
Machine Screw
Part #316.82
Qty. 2 per side

Tools



#2 Phillips
Screwdriver




3/8" Wrench

Attach the right Sunrider Pivot Bracket to the Right Door Rail using two (2) #10-32 Machine Screws, and two (2) Nylon Lock Nuts.

Repeat on the left side of the vehicle.

Step 2




Lift the Header/Side Bow Assembly onto the top of the Jeep, with the Header sitting on top of the Jeep windshield, and the fabric draped forward over the Jeep hood.

You may want to protect the finish of the Jeep by putting a blanket across the Jeep Hood.



Step 3




Attach the right Side Bow to the Right Side Bow Pivot Bracket.

- ① Pull out on the spring catch release knob;
- ② Slide the slotted end of the Side Bow over the vertical tab on the Side Bow Pivot Bracket, and release the knob, making sure that the catch snaps into place on the Pivot Bracket tab.


Repeat on the left side of the Jeep.

Parts



#2 Bow Assembly
#541.18
Qty. 1


Step 4



Attach #2 Bow to the #2 Bow Pivot Brackets on each side of the Jeep.

- ① Pull out on the knob to release the spring-loaded catch on the #2 Bow rear legs;
- ② Slide the slotted end of the catch over the #2 Bow Pivot Bracket tab protruding from the sport bar cover.

Make sure that the spring catch snaps into place on each #2 Bow Pivot Bracket tab.



Step 1

Parts

Detail



M5 x 35mm
Screw
#514.62
Qty. 2



Plastic Bushing
#473.40
Qty. 4



M5 Nylon
Lock Nut
#308.62
Qty. 2



M5 Flat Washer
Part #575.27
Qty. 2

Tools




3mm Allen
Wrench



8mm Socket



Ratchet



Detail

Secure the #2 Bow to the right Side Bow using one (1) 5x35mm Machine Screw, two (2) Plastic Bushings, one (1) M5 Flat Washer, and one (1) Nylon Lock Nut.


The Plastic Bushings go on both sides of the flat portion of the #2 Bow.

The flat washer goes between the screw and the plastic bushing.

The Nylon Lock Nut goes on the outboard side of the Side Bow.

Repeat on the left side of the Jeep.

NOTE: Do not overtighten, to avoid damaging the plastic bushings.




Lift the Header/ Side Bow up and locate the hole in the Side Bow near the Header.

Using this hole in the Side Bow, attach the #2 Bow to the Side Bow.

See detailed instructions.



Step 1



Tools




4mm Allen Wrench



10mm Wrench


Parts




Window Carrier - Left
Part #509.89
Qty. 1



Window Carrier - Right
Part #509.88
Qty. 1



Cable Bracket
Part #572.03
Qty. 2



Rear Bracket
Part #509.72
Qty. 2



M6 x14 Screw
Part #517.63
Qty. 4



M6 Nylon Lock Nut
Part #494.01
Qty. 4




M6 Flat Washer
Part #257.93
Qty. 4

Install a Rear Bracket and a Cable Bracket onto each Window Carrier.

Attach the Brackets using the holes closest to the front of each Window Carrier (the side with the molded cap).




Install the M6 Screws and Flat Washers from the outside and the M6 Nylon Lock Nut from the inside of the Window Carrier and tighten.



Step 1

Parts

Step 2




Unzip the upper rear sport bar cover and locate the upper sport bar bolts. Remove the two (2) bolts and set them aside to be reused.

Cut two (2) horizontal slits the same width as the tabs on the Rear Bracket in the sport bar cover 1/4" below the zipper and aligned with the bolt hole.

Orient each Window Carrier Assembly so the plastic cap with "B" logo is toward the front and the open end of the Carrier is toward the rear.

Use the bolts that were removed to mount each Window Carrier Assembly to the sport bar. Zip sport bar cover closed.


Repeat on both sides of the vehicle.



Step 1

Parts

Step 2



Halo Frame
Part # 509.82
Qty. 1



M6 x 14 Screw
Part # 517.63
Qty. 4



M6 Washer
Part # 257.93
Qty. 4



M6 Nylock Nut
Part # 494.01
Qty. 4


Tools



4mm Allen
Wrench



10mm Wrench




Attach the Halo Frame to the Window Carrier.

Repeat on both sides of the Jeep.

Secure the Halo Frame to the Window Carrier using two (2) M6 x 14 Screws and two (2) M6 Washers 3 from the outside and two (2) M6 Nylock Nuts #494.01 from the inside.

Repeat on both sides of the Jeep.




Step 1


Parts




Halo Center
Part # 509.80
Qty. 1



Position the Halo Center on the Halo Frame.
No fasteners required for this step.




Step 1



Install the Right and Left Halos to the Window Carrier.

Install the tab feature on the upper section of each Halo in the open end of the window carrier.

Secure with two (2) M6 x 25 Screws and two (2) M6 Washers from the outside and two (2) M6 Nylon Lock Nuts from the inside in the outermost holes on each side.



Parts



Halo - Left
Part # 509.77
Qty. 1



Halo - right
Part # 509.76
Qty. 1



M6 Nylock Nut
Part # 494.01
Qty. 4



M6 Washer
Part # 257.93
Qty. 4



M6 x 25 Screw
Part # 431.62
Qty. 4

Tools



4mm Allen
Wrench





10mm Wrench


Step 2

Parts

Step 3



Strut Bracket - Right
Part #509.64
Qty. 1



Strut Bracket - Left
Part #509.63
Qty. 1



M6 Nylock Nut
Part # 494.01
Qty. 4



M6 Washer
Part # 257.93
Qty. 4



M6 x 25 Screw
Part # 431.62
Qty. 4


Tools



4mm Allen
Wrench




10mm Wrench



Hook each Strut Bracket under the belt rail inside the vehicle and rotate up.


Secure bracket to Halo and belt rail.
Repeat on both sides of the vehicle.



Step 4

Parts

Tools



M8 x 20 Screw
Part # 493.96
Qty. 2



M8 x 20 Nylon
Lock Nut
Part # 434.12
Qty. 2



M8 Washer
Part # 433.98
Qty. 4



13mm Wrench



Ratchet




13mm Socket

Use M8 x 20 Screws, M8 Washers and M8 x 20 Nylon Lock Nuts to secure the Halo to the belt rail on each side of the vehicle.


It may be easier to install the bolts from the bottom up with the nut on top.

Repeat on both sides of the vehicle.




Step 1

Parts




Halo Seal (Long)
Part # 510.17
Qty. 1



Install the Halo Seal on the Halo.

Start at the bottom on each side and work toward the center.

Align the bottom of the seal to match the angle on the tailgate opening.



Step 1

Parts



M6 Nylock Nut
Part # 494.01
Qty. 4



M6 Washer
Part # 257.93
Qty. 4



M6 x 25 Screw
Part # 431.62
Qty. 4


Tools



4mm Allen
Wrench




10mm Wrench



With at least 2 people, install the Rear Window Glass on the Halo.

Secure with two (2) M6 x 25 Screws and two (2) M6 Washers from the outside and two (2) M6 Nylon Lock Nuts from the inside in the holes for the hinges on each side of the Halo.



Important

2 or more people are required to install the Rear Window Glass.

Importante

Se requiere 2 ó más personas para la instalación de la ventana de vidrio trasera.

Important

La mise en place de la lunette arrière en verre nécessite au moins deux personnes.



CAUTION

Take extra care fastening the gas strut brackets and the upper hinge plates to safety glass hatch. Over tightening may result in cracking or breaking the glass hatch.



Precaución


Tenga mucho cuidado al fijar los soportes de los puntales a gas y las placas con bisagras superiores a la luneta de cristal. Apretar más de lo necesario puede resultar en agrietamiento o rotura de la luneta de vidrio.



Attention

Apporter un soin très particulier à la fixation des étriers des vérins à gaz et des plaques des charnières supérieures sur la lunette en verre de sécurité. Un serrage trop important peut craqueler ou casser la lunette en verre.

Step 1



To install the Struts: ① Secure the top (tube section) of the Strut to the Rear Window Glass by pressing the end onto the round stud. ② Secure the bottom to the lower Strut Bracket.

You may have to rotate the end of the Strut to align properly with the stud.


Repeat with both Struts.



Parts

Strut
Part #510.16
Qty. 2

To Remove



Flat Blade
Screwdriver

Tools



Flat Blade
Screwdriver



CAUTION

Take extra care fastening the gas strut brackets and the upper hinge plates to safety glass hatch. Over tightening may result in cracking or breaking the glass hatch.



Precaución

Tenga mucho cuidado al fijar los soportes de los puntales a gas y las placas con bisagras superiores a la luneta de cristal. Apretar más de lo necesario puede resultar en agrietamiento o rotura de la luneta de vidrio.




Attention

Apporter un soin très particulier à la fixation des étriers des vérins à gaz et des plaques des charnières supérieures sur la lunette en verre de sécurité. Un serrage trop important peut craqueler ou casser la lunette en verre.

To Remove

③ Use a flat blade screwdriver to pry up the retainer ring and then ② pull the end off round stud to remove the strut.

Repeat with both Struts.




Step 1

Parts




Rear Seal (short)
Part #511.87
Qty. 1



Install the Rear Seal on the bottom of the Rear Window Glass.

Start on the outside edges and work toward the center.




Step 1


Parts



Upper TG Panel Seal
Part #514.04
Qty. 2




Lower TG Panel Seal
Part #514.05
Qty. 2




Install the TG Panel Seals on the tailgate panel.

The Upper TG Seal aligns with the top and the Lower TG Seal aligns with the Upper TG Seal.




Step 1

Parts



- ① Insert the Rear Arch Bow into the plastic mounting slot on the near side Window Carrier.
- ② While pushing up in the middle of the bottom of the Bow;
- ③ Push the opposite end of the Bow inward to flex the Bow and insert it into the slot in the opposite side of the Window Carrier.



Step 1

Tighten glass hinge fasteners.

Tighten Window Carrier fasteners.


Tighten bolts on sport bar holding Rear Brackets.

Zip sport bar covers closed.

Tighten all Halo frame fasteners, including lower Halo Strut Bracket and Halo lower screws.

Passenger side fastener locations shown.

Repeat on both sides of the vehicle.



Step 2

Open and close the rear window.


Make sure the window operates smoothly.

Make sure the window is centered in the opening and has a nice even gap and good seal contact on all sides.


Step 1

Parts


Step 2



Foam Tape Strips
Part #417.43
Qty. 1 per side




Foam Seals
Part #457.76 Right
Part # 457.77 Left
Qty. 1 per side




Peel the backing off the Foam Seals and install them on each side of the Header as shown above.

Peel the backing off the Foam Tape Strips and install them on each side of the Header.



Section 19 Lay Top Fabric Over the Jeep; Open Sunrider and Secure Cable Spring


Step 1



Lay the Top Fabric back across the top of the Jeep.


Open the Sunrider by folding the Header back.

Step 2




Hook the cable spring into the Cable Bracket on the Window Carrier. Crimp the spring to secure it to the Cable Bracket.

Repeat on both sides of the vehicle.




Step 1



Start at the rear of the Window Carrier and slide the tube on the top of the Right Side Window into the slot in the Window Carrier.

Repeat on the left side of the vehicle.


Step 2




Tuck the plastic angle strip along the front edge of the Quarter Window into the vertical channel on the front of the Rear Door Rail. The plastic angle strip and attached fabric must be rolled into place in the channel.

Repeat on the left Quarter Window.

When installed correctly, there will be only one (1) stitch line visible and it will be facing the door opening.




Step 3

Start at the front and work from front to back to install the retainer along the bottom of the window. Tuck the retainer under the vehicle belt rail.

You can adjust the window front-to-back if needed but the fabric will be tight


Repeat on the both sides of the vehicle.

Step 4


Install the rear corner retainer. Tuck the retainer under the vehicle belt rail.

You can adjust the window front-to-back if needed but the fabric will be tight

Repeat on the both sides of the vehicle.




Step 5




Start at the bottom and roll the retainer into the slot in the Rear Halo. Work up from bottom to top.

Repeat on the both sides of the vehicle.




Step 1




Start in the middle and roll the retainer into the slot in the Rear Halo above the Rear Window hinges.

This operation is made easier if the Sunrider is open for both installation and removal of top and windows.


Step 2




Install the side retainers into the Window Carrier




Step 3



Engage rear corner hook-and-loop on both sides of the vehicle.




Step 4




Locate the two straps and buckles attached to the inside of the top fabric.

With the Sunrider halfway open, and while looking down on top of the soundbar and sportbar, thread the long end of each strap between the plastic portions of the soundbar, and the metal sportbar, so that the strap wraps completely around the metal sportbar.

Attach the end of each long strap to the buckle, and snug. Do not overtighten.




Step 1



Close the Sunrider.


Step 2




Hook the latches on the windshield header into the loops on the windshield.

Do not close the latch.


Repeat on the opposite side of the vehicle.



Step 3



Close the latches on both sides of the windshield header.



Original Soft Top Only



Model Years 2007-2010



Model Years 2011+

Original Soft Top Only


Purchase a MOPAR wiring harness (not included) and install according to MOPAR directions.

Model Years 2007-2010: #82210215

Model Years 2011+

- without heated mirror: #82212859


- with heated mirror: #82212860




Step 1

Parts

Step 2



Jumper Harness
Part #510.18
Qty. 1




Attach Harness to Rear Glass heater grid terminals and route the wiring back to the existing OE harness.


Use the "P" clips and the screws provided in the harness kit to route the wires.

Remove any caps covering the metal clip.

Attach Jumper Harness to existing vehicle wiring harness.


You will need to re-use the original washer fluid connector for the Trektop PRO Plus washer fluid tube.





Sold Separately

5485801 Rear Wiper Motor Kit



Sold Separately

5485701 Heater Grid Only Harness



Care and Maintenance of your Bestop Product

Your Bestop product is made of the finest materials available. To keep it looking new and for the maximum possible wear, it will need periodic cleaning and maintenance.


Fabric: The fabric should be washed often using soap, warm water and a soft bristle brush. Rinse with clear water to remove all traces of soap. Bestop recommends using Bestop Cleaner (part no. 11201-00) and Bestop Protectant (part no. 11202-00) for Vinyl fabric and Bestop Twill Protectant (part no. 11207-00) for Twill fabric. Bestop Cleaner and Bestop protectant are specially formulated to provide a total cleaning and protection system. Bestop Cleaner safely removes the toughest stains, will not harm vehicle finishes, is biodegradable and environmentally friendly. Bestop Protectant protects against UV-fading, cracking and hardening, and repels dust, grease, dirt and mildew.

Windows: Keep windows clean to avoid scratching. DO NOT use a brush on the windows! Wash with a water-soaked cloth or sponge and a mild dishwashing detergent. Bestop recommends Bestop Vinyl Window Cleaner (part no. 11203-00), which safely cleans and protects vinyl windows and helps prevent UV damage. NEVER WIPE THE WINDOWS WHEN THEY ARE DRY. Be careful when cleaning snow or frost from the vinyl windows since they are easily scratched and may crack at low temperatures. DO NOT roll the sides or rear window in cold weather. The windows become stiff and will crack. Cracks caused by misuse in cold temperatures are not covered under warranty.

Water: Seeping through at the seams may be stopped by applying 3-M Scotchgard® on the inside of the seams.

Snaps: Keep snaps cleaned and lubricated with silicone to help prevent snaps from sticking to the studs. If a snap does become stuck to a stud, use a screwdriver and GENTLY pry apart to prevent permanent damage to the snap or the top fabric.

Zippers: Keeping zippers cleaned and lubricated with Bestop's Zipper Cleaner (part no. 11206-00) will help prevent damage and keep the zippers in smooth working condition. If a zipper opens behind the slider, the slider may have been spread apart. This problem can usually be repaired by using an ordinary pair of pliers to bring the sides back into parallel. Return slider to the end of the zipper in the normal Open position. Squeeze lightly at first and test the zipper. If the zipper continues to remain open squeeze more firmly with the pliers and try the zipper again. Repeat this procedure until the zipper operates correctly.



For Bestop Warranty Information, Please go to;
<https://www.bestop.com/help/warranty-information/>

